



LED T8 Ballast Compatibility Chart

Ballast Brand*	Part Number	# Of Lamps	Start Method	1 Lamp	2 Lamps	3 Lamps	4 Lamps
Advance	R-2S40-1-TP	2	/	X	✓	N/T	N/T
Advance	VEL-2P59-S-RH-TP	2	/	✓	✓	N/T	N/T
Advance	HM-1P20-TP	1	/	✓	N/T	N/T	N/T
Advance	REL-4P32-RH-TP	4	/	✓	✓	X	X
Advance	RL-2SP20-TP	2	/	N/T	✓	N/T	N/T
Advance	R-140-1-TP	1	/	✓	N/T	N/T	N/T
Advance	V-140-2-TP	1	/	✓	N/T	N/T	N/T
Arcata	ACT4P32ISUNVE	4	Instant Start	N/T	✓	✓	✓
Basic-12	B260IUNVHP	2	/	✓	✓	N/T	N/T
Espen	VE2P32MVHPPE 11080	2	Instant Start	✓	✓	N/T	N/T
Espen	VE4P32MVHPPE 11086	4	Instant Start	✓	✓	✓	✓
Espen	VE4P32MVHIPE 11072	4	Instant Start	✓	✓	✓	✓
Espen	VE3P32MVHIPE 11070	3	Instant Start	✓	✓	✓	N/T
Espen	VE4P32MVHIPHE 11073	4	Instant Start	✓	✓	✓	✓
Espen	VE4P32MVHIPE 11072	4	Instant Start	✓	✓	✓	✓
Espen	VE3P32MVHPPE 11083	3	Instant Start	✓	✓	✓	N/T
Espen	VE232MVHIPE	2	Instant Start	✓	✓	N/T	N/T
Espen	VE2P32MVHIPHE 11069	2	Instant Start	✓	✓	N/T	N/T
Espen	VE2P32MVHIPE 11068	2	Instant Start	✓	✓	N/T	N/T
Espen	VE2P32MVHIPE 11068	2	Instant Start	✓	✓	N/T	N/T
Espen	VE232MVHIPE	2	Instant Start	✓	✓	N/T	N/T
GE	GE240RES120-B	2	Instant Start	✓	✓	N/T	N/T
GE	GE240RES120-4PK	2	Instant Start	✓	✓	N/T	N/T
GE	GE232MVPS-N-VO3	2	Instant Start	✓	✓	N/T	N/T
GE	GE132MAX-H/ULTRA	1	Instant Start	✓	N/T	N/T	N/T
GE	GE132MAXP-L/ULTRA	1	Instant Start	✓	N/T	N/T	N/T
GE	GGE-132-MV-PS-L	1	Instant Start	✓	N/T	N/T	N/T
GE	GE-132-MV-N	1	Instant Start	✓	N/T	N/T	N/T
GE	GE132-MVPS-H	1	Instant Start	✓	N/T	N/T	N/T
GE	GE-132-MV-N	1	Instant Start	✓	N/T	N/T	N/T
GE	GE132-MVPS-H	1	Instant Start	✓	N/T	N/T	N/T
GE	E232MAXP-H/ULTRA	2	Instant Start	✓	✓	N/T	N/T
GE	GE232-MV-PS-H	2	Instant Start	✓	✓	N/T	N/T
GE	E232MAXP-H/ULTRA	2	Instant Start	✓	✓	N/T	N/T
GE	GE232-MVPS-L	2	Instant Start	✓	✓	N/T	N/T
GE	GE232-MVPS-N	2	Instant Start	✓	✓	N/T	N/T
GE	GE232MAX-G-N	2	Instant Start	✓	✓	N/T	N/T
GE	GE-232-MVPS-XL	2	Instant Start	✓	✓	N/T	N/T
GE	GE232MAX-G-N-DIYB	2	Instant Start	✓	✓	N/T	N/T
GE	GE232MAX-L/ULTRA	2	Instant Start	✓	✓	N/T	N/T
GE	GE-232-MV-N	2	Instant Start	✓	✓	N/T	N/T
GE	GE-232-MV-PS-H	2	Instant Start	✓	✓	N/T	N/T
GE	GE232MAXG-N-DIYB	2	Instant Start	✓	✓	N/T	N/T
GE	GE332MAXP-H-42T	3	Instant Start	✓	✓	✓	N/T
GE	GE332MAX-G-N	3	Instant Start	✓	✓	✓	N/T
GE	GE332-MVPS-L	3	Instant Start	✓	✓	✓	N/T
GE	GE332MAXP-L/ULTRA	3	Instant Start	✓	✓	✓	N/T
GE	GE332MAXP347-H	3	Instant Start	✓	✓	✓	N/T
GE	GE332MAX-G-H	3	Instant Start	✓	✓	✓	N/T
GE	GE332MAX-G-N-DIYB	3	Instant Start	✓	✓	✓	N/T
GE	GE332MV-N-DIY	3	Instant Start	✓	✓	✓	N/T
GE	GE432MAXG-N-DIYL	4	Instant Start	✓	✓	✓	✓
GE	GE432MAXP347-H	4	Instant Start	N/T	✓	✓	✓
GE	GE432MAX-G-N	4	Instant Start	✓	✓	✓	✓
GE	GE432MAX90-V60	4	Instant Start	✓	✓	✓	✓
GE	GE432MAXPH/ULTRA	4	Instant Start	✓	✓	✓	✓
GE	GE432MAXP-L/ULTRA	4	Instant Start	✓	✓	✓	✓
GE	GE232MAX-N/ULTRA	2	Instant Start	✓	✓	N/T	N/T
GE	GEM220TS120	2	/	X	✓	N/T	N/T
GE	GEM240RS277	1	/	✓	X	N/T	N/T
Halco	EP332IS/L/MV/HE	3	Instant Start	✓	✓	✓	N/T
Halco	EP432IS/L/MV/HE	4	Instant Start	✓	✓	✓	✓
Halco	EP232IS/MV/HE	2	Instant Start	✓	✓	N/T	N/T
Halco	EP332IS/MV/HE	3	Instant Start	✓	✓	✓	N/T
Halco	ISL432T8HEMV 3P20160	4	Instant Start	✓	✓	✓	✓
Keystone	KTEB-228HE-UV-PS-SL	2	Instant Start	✓	✓	N/T	N/T
Keystone	KTEB-332-UV-IS-N-P	3	Instant Start	✓	✓	✓	N/T
Keystone	KTEB-432RIS-1-TP-SL	4	Instant Start	✓	✓	✓	✓
Osram	QTP 2X32T8/UNV ISN-SC	2	Instant Start	✓	✓	N/T	N/T
Osram	QHE 2X32T8/UNV ISL-SC	2	Instant Start	✓	✓	N/T	N/T
Osram	QHE 2X32T8/UNV ISL-SC-1	2	Instant Start	✓	✓	N/T	N/T
Osram	QHE 2X32T8/UNV ISH HT-SC	2	Instant Start	✓	✓	N/T	N/T
Osram	QHE 2X32T8/UNV PSX-MC	2	Instant Start	✓	✓	N/T	N/T
Osram	QHE 2X32T8/UNV ISH HT-SC	2	Instant Start	✓	✓	N/T	N/T
Osram	QHE 2X32T8/UNV ISL-SC	2	Instant Start	✓	✓	N/T	N/T



LED T8 Ballast Compatibility Chart

Ballast Brand*	Part Number	# Of Lamps	Start Method	1 Lamp	2 Lamps	3 Lamps	4 Lamps
Osram	QHE 2X32T8/UNV PSN-MC	2	Instant Start	✓	✓	N/T	N/T
Osram	QHE 2X32T8/UNV ISH HT-SC	2	Instant Start	✓	✓	N/T	N/T
Osram	QHE 3X32T8/UNV ISH HT-SC	3	Instant Start	✓	✓	✓	N/T
Osram	QTP 3X32T8/UNV ISN-SC	3	Instant Start	✓	✓	✓	N/T
Osram	QTP 4X32T8/UNV ISN-SC	3	Instant Start	✓	✓	✓	N/T
Osram	QHE 4X32T8/UNV ISL-SC	4	Instant Start	✓	✓	✓	✓
Osram	QHE 3X32T8/UNV PSN-SC	3	Instant Start	✓	✓	✓	N/T
Osram	QTP 4X32T8/UNV ISL-SC	4	Instant Start	✓	✓	✓	✓
Osram	QHE 2X32T8/UNV ISN-SC	2	Instant Start	✓	✓	N/T	N/T
Osram	MB2X40/120 RS	2	/	✓	✓	N/T	N/T
Philips Advance	REL8-2S40-N	2	Instant Start	X	✓	N/T	N/T
Philips Advance	ICN-2S40-N	2	Instant Start	✓	X	N/T	N/T
Philips Advance	REL-4P32-RH-TP	4	Instant Start	✓	✓	✓	✓
Philips Advance	IOPA-1P32-LW-N	1	Instant Start	✓	N/T	N/T	N/T
Philips Advance	IZT-132-SC	1	Instant Start	✓	N/T	N/T	N/T
Philips Advance	ICN-1P32-N	1	Instant Start	✓	N/T	N/T	N/T
Philips Advance	IOP-2P32-HL-N	2	Instant Start	✓	✓	N/T	N/T
Philips Advance	ICN-2P32-N	2	Instant Start	✓	✓	N/T	N/T
Philips Advance	IOP-2PSP32-LW-N	2	Instant Start	✓	✓	N/T	N/T
Philips Advance	IOPA-2P32-LW-N	2	Instant Start	✓	✓	N/T	N/T
Philips Advance	REL-2P32-SC	2	Instant Start	✓	✓	N/T	N/T
Philips Advance	IOP-2P32HL-SC	2	Instant Start	✓	✓	N/T	N/T
Philips Advance	IOPA-2P32-N	2	Instant Start	✓	✓	N/T	N/T
Philips Advance	IOP-2P32-LW-N	2	Instant Start	✓	✓	N/T	N/T
Philips Advance	IOPA-3P32-N	3	Instant Start	✓	✓	✓	N/T
Philips Advance	REL-3P32-SC	3	Instant Start	✓	✓	✓	N/T
Philips Advance	IOPA-3P32-LW-N	3	Instant Start	✓	✓	✓	N/T
Philips Advance	ICN-3P32-N	3	Instant Start	✓	✓	✓	N/T
Philips Advance	IOPA-3P32-LW-SC	3	Instant Start	✓	✓	✓	N/T
Philips Advance	ICN-4P32-N	4	Instant Start	✓	✓	✓	✓
Philips Advance	IOP-4PSP32-SC	4	Instant Start	✓	✓	✓	✓
Plusrite	BAF232PS/MV	2	Instant Start	✓	✓	N/T	N/T
Plusrite	BAF432IS/MV	4	Instant Start	N/T	✓	✓	✓
Sylvania	QHE 1X32T8/UNV ISL-SC	1	Instant Start	✓	N/T	N/T	N/T
Sylvania	QHE 4X32T8/UNV ISL-SC	4	Instant Start	✓	✓	N/T	N/T
Sylvania	QTP 1X32T8/UNV ISN-SC	1	Instant Start	✓	N/T	N/T	N/T
Sylvania Osram	MB1x40/277 RS	1	/	✓	N/T	N/T	N/T
TCP	E3P32ISUNVE	3	Instant Start	✓	✓	✓	N/T
TCP	E4P32ISUNVE	4	Instant Start	✓	✓	✓	✓
Triad	B232IUNVHP-N	2	Instant Start	✓	✓	N/T	N/T
Triad	B432IUNVHP-A	4	Instant Start	✓	✓	✓	✓
Triad	B432IUNVHE-A	4	Instant Start	✓	✓	✓	✓
Triad	B332IUNVEL-A	3	Instant Start	✓	✓	✓	N/T
Universal	M2/40RS-120	2	/	X	✓	N/T	N/T
Universal	458-L-SLH-TC-P	1	/	✓	N/T	N/T	N/T
Universal	413-C-TC-P	2	/	✓	✓	N/T	N/T

Applies to the
following Satco products:

S26500

✓ Compatible
X Not Compatible
N/T Not Tested

This list is current as of Feb. 2025. We are continuously testing for compatible ballasts. Please check back for updates.

* All trademarks are the property of their respective owners

110 Heartland Blvd.
Brentwood, NY 11717
PH 631-243-2022
FX 631-243-2027

Distribution Centers
New York, Florida,
Texas, Washington,
California, Puerto Rico

National Toll-Free
800-43-SATCO
(800-437-2826)
www.satco.com

Copyright© 2025
Satco Products, Inc.
All Rights Reserved.
Rev: February 4, 2025